



Installation Instruction

Performance Turbo Inlet pipe



SAAB NG 9-5 2.0T 2010-2011

This installation instruction is based on an install on a MY2010 SAAB 9-5 2,0T.
Cars with other engines might differ a bit in some steps.



Description

This instruction shows how to replace the OEM Turbo inlet pipe with do88 performance turbo inlet pipe.

At this type of installation we always recommend that you have mechanical experience and knowledge about safety during work on vehicles.

Parts List

- 1pc do88 Performance turbo inlet pipe
- 2pcs do88 silicone hoses
- 1pc 50-70mm hose clamp
- 3pcs 70-90mm hose clamps
- 2pcs 14-15mm hose clamp
- 1pc aluminum nipple
- 6cm 8mm hose



Step 1

Loosen the 7mm hose clamp and remove connector to vacuum line.



Step 2

Loosen the 7mm hose clamp and remove the OEM inlet pipe from the car.
Install do88 turbo inlet pipe with included accessories.



Step 3

Install the included 8mm hose with the included aluminum nipple at the end of the hose with 2x 14-15mm hose clamps.

Re-install all other parts in reverse order.



Thank you for purchasing another do88 product.

Please check our website frequently for new product releases.
If you have any questions or concerns about this product please do not
hesitate to contact us: do88.se/contact