

# Installation instruction do88

## Performance Radiator for Volvo 740 940

Part Number: WC-240



1.

This instruction shows how to replace the OEM radiator with this do88 performance radiator.

At this type of installation we always recommend that you have mechanical experience and knowledge about safety during work on vehicles.

Parts included:

1. Performance radiator



1. Drain the engine coolant by removing drain screw in the lower right corner of the radiator.

2. Disconnect all 4 hoses from the radiator.

3. Remove the fan shroud 3x Philip screws. And lift the fan shroud away a bit.

4. Remove the 2 top radiator brackets. 2x Hex 10mm.

5. Remove the 2x Torx T25 from the top of the radiator.

6. Now remove the radiator from the car.

7. Reinstall all other parts in reverse order.

